




hager








VF

- (F) Coffret à encastrer
- (GB) Flush enclosure
- (D) Unterputzverteiler
- (I) Centralini da incasso
- (E) Caja empotrable
- (P) Caixa para encastrar
- (S) Kapsling
- (NL) Inbouwverdeelkast



Notice d'instructions
User instructions
Bedienungsanleitung
Istruzioni d'impiego
Instrucciones de uso
Instruções
Bruksanvisning
Gebruiksaanwijzing



$r = 1, 2, 3$



	A (mm)	B (mm)	C (mm)
4 I	162	220	22
8 I	250	230	17
12 I	322	265	17
24 I	322	390	17
36 I	322	535	17



	E (mm)	F (mm)	P (mm)
4 I	140	175	73
8 I	209	189	77
12 I	281	224	80
24 I	281	349	80
36 I	281	491	80

